Fax: 2710 8012 Tel: 2388 7171 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk

PROJECT	REF	REV	ITEM CODE	
LOCATION	DATE		PAGE	

## SANITARY WARE SPECIFICATION SHEET

**Item Descriptions** Mediclinics "Machflow®" (Spain) Steel

wall-mounted automatic hand dryer in white

epoxy finish

Dimensions L213 x W170 x H330 mm

M09A Model

Material/Finish Steel / White Epoxy Finish

Manufacturer Mediclinics, S.A. (Spain)

Supplier Acme Sanitary Ware Co. Ltd

Mr. Eric Wong/ Mr. Don Yuen

Contact Tel/Fax (852) 2388-7171 / (852) 2710-8012

E-mail acme@acmesanitary.com.hk Website www.acmesanitary.com.hk

### General description

- · Sensor operated Machflow Plus hand dryer, available in steel, white or black finish and in AISI 304 stainless steel, bright or satin finish.
- With a compact and very robust design, this hand dryer is energetically very efficient and sustainable, providing great energy savings and ultra-fast hand drying. Strongly recommended for high traffic places.
- · It has an adjustable power motor that regulates energy consumption (between 420 and 1,500W) and provides a maximum air output speed of 325 km/h that dries your hands between 10 and 15 seconds.
- · Optionally, it is also possible to incorporate a quick assembly / disassembly kit for the machine ("Plug-in" kit code KTP009) that allows you to install and uninstall the hand dryer easily, quickly and Matte black epoxy finish safely, making maintenance much more efficient and reducing your costs at the same time.
- · New air concentrator nozzle which helps to channel better the airflow on the hands. Instead of blowing air all over the hands, it focuses the airflow for a more targeted drying. The narrower opening of the concentrator gives the airflow greater pressure on exit, boosting its speed and thus, making the hand drying process much more efficient.
- $\cdot\,\,$  It has an odor neutralizer, code RCPOM14 that aromatizes and deodorizes the environment thanks to its soft fragrance (optional).
- Machflow Plus is equipped with an automatic safety disconnection system that switches it off automatically after 60 seconds of
- It is supplied as standard with all the elements to fix it to a brick wall.



M09A White epoxy finish



M09AB







M09ACS Satin finish



Technical Specifications	
Voltage	220- 240 V
Frequency	50/60 Hz
Electrical Isolation	Clase I
Total power	420 – 1,500 W
Consumption	3.2 -6.4 A
Standby consumption	0.3 W
Motor power	420 – 1,100 W
Rpm	19,000 – 30,000
Heating element power	400 W (interruptor "ON/OFF")
Dimensions	330x213x170 mm
Weight	5.1 Kg
Cover thickness	1.5 mm
Drying time	10-15"
Effective airflow	115-180 m3/h -1,917-3,000 L/min
Air velocity	191 – 325 Km/h
Air temperature (10 cm	45 °C
distance/21ºC)	
Sound pressure (*) (at 2m)	67-74 dBA
Protection rating	IP23
(*) According to UNE EN ISO 11201::	2010 V2 standard

Note: YouTube https://youtu.be/qDUU0ues3DE









## Acme Sanitary Ware Co Ltd

Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk

PROJECT	REF	REV	ITEM CODE	
LOCATION	DATE		PAGE	

### SANITARY WARE SPECIFICATION SHEET


#### Components and materials

- COVER: made of steel (M09A...and M09AB...) or AISI 304 stainless steel (M09AC...and M09ACS...) of 1.5 mm thickness, in one piece without welding.
- · BASE PLATE: made with PA6V0 fire resistant plastic. It incorporates 4 silent-blocks to cushion mechanical vibrations.
- **INTERIOR SET**: made of PA6V0 fire resistant plastic.
- MOTOR: vacuum universal brush motor, F class. Speed may be adjusted manually between 19.000 and 30.000 rpm by means of a potentiometer.
- **HEATING ELEMENT**: minimum waved wire NiCr heating element of 400W, mounted on a mica frame that incorporates a self-resetable thermal cut-off which disconnects the whole appliance. The heating element can be disconnected by means of a ON/OFF switch.
- HANDS DETECTION SYSTEM: fully adjustable IR electronic detection sensor by means of a potentiometer. Detection distance can be adjusted between 5and 25 cm. It has an automatic disconnection system after 60 "of continuous use.
- ODOR NEUTRALIZER: aromatizes and deodorizes the environment through its soft fragrance (optional).

### Operation

Place the hands under the air outflow valve. The dryer will start automatically, and go on with no interruption as long as the hands are kept in the detection range of the sensor. The appliance will stop 2 seconds after the handsare removed from the airflow or 60 seconds after continuous working.

### Mounting (Recommended hights distance from the floor)



Codes	Cover material	Cover finish
M09A	Steel	White
M09AB	Steel	Black
M09AC	Stainless steel	Bright
M09ACS	Stainless steel	Satin



Heating element ON/OFF switch Option to turn ON/OFF the heating element



Heating element For a maximun comfort



The Machflow® Plug-in technology is an easy, practical, fast and secure system to install and uninstall the hand dryer (optional)

Maintenance videos YouTube

Cover removal: https://youtu.be/tNETgUZ4Ypc

Distance detection and power adjustment: https://youtu.be/AsIxFP3GJcs Electronic circuit board replacement: https://youtu.be/aiWwbwWuqio

Motor replacement: https://youtu.be/yEqs69A6vL0

Carbon Brushes Replacement : https://youtu.be/WD\_omt-MeCc Heating element replacement: https://youtu.be/Lu3kCLsYExE

Note: YouTube https://youtu.be/qDUU0ues3DE











# **Acme Sanitary Ware Co Ltd**

Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk

PROJECT	REF	REV	ITEM CODE	
LOCATION	DATE		PAGE	

## SANITARY WARE SPECIFICATION SHEET

### PLUG-IN SYSTEM


Note:


YouTube

The Machflow® Plug-in technology is an easy, practical, fast and secure system to install and uninstall a hand dryer, making maintenance much more efficient and reducing at the same time its costs.

With the Machflow® Plug-in technology a hand dryer can be installed in a few steps and it can be replaced in less than 10 seconds thanks to its SMED (Single-Minute Exchange of Die) system. Furthermore its maintenance can be carried out better at the maintenance workshop and it is totally secure against electric shocks. All of these benefits allow you to reduce the

This fast install/uninstall technology to the wall is optional and it is carried out by means of a special kit code: KTP009.





https://youtu.be/qDUU0ues3DE

Your Plug-in base is now ready used with a Plug-in dryer

## Acme Sanitary Ware Co Ltd

Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk

Table

## HAND DRYERS

				la un	Iaoi		41							
	MODEL	OPERA	ATION	ION DIMINENSIONS				ADJUSTABLE	MOTOR			TRAFFIC FREQUENC		JENCY
		manual sensor (mm)		lonizer HEPA fil media )rain Pi <sub>l</sub>	POWER	induction	bruch	brushless	нісн	MEDIUM	LOW			
		manuai	SCIISOI	(11111)	<u> </u>	포트	Dra		induction	brusn	brusniess	пібп	MEDIUM	LOW
	dualflourp	US									G	ualfla	urolus	
-	M24A		•		*	•	8				•	•		
	M24AB		•	1	*	•	*				•	•		
	M24ACS		•	L320xD228xH665	*	•					•	•		
	M14A		•	LSZUXDZZOXH00S	*	•		•		•		•		
	M14AB		•	]	*	•		•		•		•		
	M14ACS		•		*	•		•		•	1.0	•	10	
	mochflow p			_			mo	chflow plu		achilow.				
	M19A M19AB		•		*	8		•			•	-		
	M19AC			1	*	*						÷		
	M19ACS				*	*						-		
	M09A		•	L213xD170xH330	*	*		•		•		•		
	M09AB		•	]	*	*		•		•		•		
	M09AC		•		*	*		•		•		•		
	M09ACS		•	-10	*	*		•		• 10		•	10	
	speedflou	plus,		arlow.					S		ow plus/	_	arlow.	
	M17A M17AB		•		*	•		•		•		•		
-	M17AC		÷		*	÷		•		·				
	M17ACS		•		*	÷				•				
- Itte	M17AF		•	L290xD100xH270	*	•		•		•		•		
	M06A		•	(INSIDE CABINET)				•		•		•		
	M06AB		•	[				•		•		•		
	M06AC		•					•		•		•		
	M06ACS M06AF		•					•		•		•		
	soniflow*							•		_			niflow•	
1-	E05	•								•		0	III (OW	
	E05B	•		L276xD214xH245						•		•		
16 18	E05C	•		LZ/0XUZI4XHZ45						•		•		
	E05CS	•								•		•		
	E85	•		L282xD215xH255						•		•		
	E88 E88B	•		1						•		•		
	E88C	•		L278xD212xH248						•		·		
	E88CS	•								•		0		
	E88O	•		i						•		•		
	E05A		•		•					•		•		
	E05AB		•	L276xD214xH245	•					•		•		
Mark man	E05AC E05ACS		•	LETONBETTATIETS	•					•		•		
	E85A		•	LagavDatevHace	•					•		•		
	E88A		•	L282xD215xH255	÷					÷		•		
	E88AB		•		•					•		•		
	E88AC		•	L278xD212xH248	•					•		•		
	E88ACS		•		•					0		•		
	E88AO		•		•					•		0	diflour	
	mediflow•				_							me	diflow	
(C)	M02A M02AB		•		•					•			•	
	M02AC		•		÷					•			•	
	M02ACS		•	L275xD164xH325	•					•			•	
	M03A		•	L2/3XD104XH325	•					•			0	
L	M03AB		•		•					•			•	
	M03AC		•		•					•			0	
	M03ACS		•		•					•			odios o	
-	M99A			L260xD150xH302								0	Juma	
	M99A M99AC		0		0				0				0	
	M99ACS		0		0				0				0	
-	iunioralus											Li	riorplus	
	M88APLUS		0	L253xD150xH303	0				0				0	
	M88PLUS	0		L253xD153xH303					0				0	
	smarttlow											SIT	artite	w
	M04A		0		0					0				0
5.	M04AC		0	L147xD138xH259	0					0				0
J. Za	M04ACS		0		0					0				0