

Acme Sanitary Ware Co. Ltd.

1/F, Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 Email: acme@acmesanitary.com.hk Since 1949 Website: www.acmesanitary.com.hk

PROJECT	REF	REV	ITEM CODE	
LOCATION	DATE		PAGE	

SANITARY WARE SPECIFICATION SHEET

Item Descriptions Bobrick (USA) Surface-mounted automatic hand dryer Dimensions Refer to drawing Model B-715E Material/Finish Stainless Steel Bobrick Washroom Equipment Inc. (USA) Manufacturer Supplier Acme Sanitary Ware Co. Ltd Mr. Eric Wong/ Mr. Don Yuen Contact Tel/Fax (852) 2388-7171 / (852) 2710-8012 E-mail acme@acmesanitary.com.hk Website www.acmesanitary.com.hk


Cover — One-piece, deep drawn, 20-gauge (0.9mm), type-304 stainless steel with satin finish. Cover is secured to mounting base with three flat-head stainless steel screws.

Mounting Base and Fan Housing — 5/64" (2mm) thick fire-retardant molded grey plastic with high-gloss finish. Plastic air-inlet grille fits into bottom of mounting base. Plastic air-outlet grille is secured between fan housing and mounting base. **Motor** — Maintenance-free capacitor run, external rotor motor with sealed ball

bearings at both ends of drive shaft. Equipped with an automatic thermal-overload switch.

Fan — Dynamically balanced 5-15/64" (133mm) diameter rotor centrifugal fan with multiple metallic vanes. Directs air flow from heating element at 100 cfm, mixes air to provide uniform temperature.

Heating Element — Coiled nickel-chrome heating element is protected by an automatic thermal-overload switch and thermal fuse. Heating element, which is located on inlet side of fan, heats air without hot spots — inaccessible to vandals. **Electronic Control** — Infrared sensor automatically turns dryer on when hands are held under air-outlet opening and across path of sensor. Remove hands from path of sensor and dryer stops. Electronic sensor has automatic shutoff approximately two minutes after dryer turns on if an inanimate object, such as tape or chewing gum, is placed across sensor lens. After inanimate object is removed, electronic sensor automatically resets itself and dryer operates normally.



Note: