



Illustration/ Drawing

PROJECT	REF	REV	ITEM CODE	
LOCATION	DATE		PAGE	

SANITARY WARE SPECIFICATION SHEET

Item Descriptions Stern (Israel) "Extreme Plus" Chrome plated deck mounted extended body sensor faucet in AC Supply with 5m wire AC 110-240 Vac 50/60Hz to 9V 0.3A IP68 waterproof switching transformers Dimensions L103 x W44 x H365 mm Model Extreme Plus E Code Number 237350 Finish Chrome Plated Acme Sanitary Ware Co. Ltd Supplier Mr. Eric Wong/ Mr. Don Yuen Contact Tel/Fax (852) 2388-7171 / (852) 2710-8012 E-mail acme@acmesanitary.com.hk Website www.acmesanitary.com.hk

EXTREME PLUS E Ref # 237350

Touch-free electronic faucet for deck-mounted installations. Activated by infrared sensor. Tall version for counter top washbasins. For cold or premixed water. Filters included. Chrome plated body, other finishes available. Includes a low battery indicator. Latching solenoid valve is located above deck inside the product for added vandal protection. Regular faucet installation with simple transformer connection. Adjustable settings by remote control: sensor range, security time, delay in, delay out, on-off and reset to factory settings. 24 hour mandatory hygiene flush available upon request.


Application:

Deck-mounted faucet. Combining an elegant minimalist design with anti-vandal features. Easy installation. Long lasting even in the harshest installation sites. Helps washrooms stay clean and saves water. Prevents cross contamination. Ideal for stadiums, train and bus stations and highway rest stops.

Use:

Touch-free electronic faucet. The faucet is automatically activated when users place their hands in the sensor range and stops when the users remove their hands.

		PRODUCT	AT A GLANCE		
Installation		Lavatory mounted			
Power Supply		9V external battery box • 12V transformer			
Operating pressure		5-8.o bar / 7.0-116.0 PSI			
Water supply		Cold and premixed water			
Water flow		6 LPM / 1.58 GPM - SSR PCA stream			
Water Saving Options		4 LPM / 1 GPM ; 3 LPM / 0.8 GPM 1.89 LPM / 0.5 GPM ; 1.3 LPM 0.35 GPM - PCA spray			
Water temperature 76		o°C Maximum			
Security Time		90 seconds. Adjustable by remote control			
ORDER	ING INFORM	ATION			
MODEL	CODE	POWER			
EXTREME PLUS B	237250	9V battery	Tall body 365 mm \ 14.37" for counter top wash basin		
EXTREME PLUS E	237350	12V transformer	late body 303 mm (14.37 Tor counter top wash basin		
EXTREME PLUS LB 23725		9V battery	Tall body 365 mm \ 14.37" for counter top wash basin		
EXTREME PLUS LE	237351	12V transformer	Long spout 176 mm \ 6.92"		










SPARE PARTS LIST



Quantity	Part Number	Description	Cat. No.
	-	Seals and Screws Kit	07210023
1	6 17	O-ring O-ring	
1	5 15a	O-ring Gasket	
2	8	Sensor Kit	07220197
1	11 5	Infra Red Sensor O-ring	
	- F	Filter Adapter Kit	07212001
1	13 14	Filter Nipple	
	4	Cover Kit	07270004
1	2	Cover O-ring	
		Solenoid Valve Kit	07230003
1	7 10	Solenoid valve Diaphragm	
	10	Diaphragm	04500001
	18	Transformer	TBC

Note: In order to locate the relevant spare part, please check the corresponding parts and part mumber in the drawing. Minimum order quantity will be required.

^{*} All information of the above is for the reference only. No prior notice is made if any changes.



本署檔號 Our ref. 來函檔號

Your ref.

(4) in WSD 3321/2020 T/J(774/2020)

電話

Tel. 傳真

2824 0578

11 August 2020

Approval of "STERN" Sensor Taps (General Acceptance No. C20200658)

Your letters ref. BE/L20403/20 and BE/L20431/20 dated 23 June 2020 and 20 July 2020 respectively refer.

Having considered the test report ref. J25246Ar1 issued on 16 July 2020 by Nutek Systems (HK) Ltd., this Authority accepts that the fittings described below comply with, and their use when correctly installed does not contravene, the Waterworks Ordinance and Regulations.

Name of Manufacturer:

Y Stern Engineering (1989) Ltd

Country of Origin:

Israel

Brand:

Stern

Details of Fittings:

3/8" Electronic sensor basin tap

Model:

237250 and 237350

Body Markings:

Sterm

Expiry Date:

23 April 2025





This Authority hereby permits the use of the above fittings in fresh water plumbing systems subject to full adherence to Waterworks installation requirements. In particular, you are required to draw your customers' attention to the following requirement-

"A stop cock or gate valve must be installed at the upstream of the fittings for manual isolation of water supply." AND

"The main voltage operated sensor valve should comply with the electricity safety regulation for applications in bathroom, toilet etc."

A condition of this acceptance is that the fittings to be installed shall be replicas of the samples as certified by the testing agent mentioned above and without modifications. This acceptance may be withdrawn at any time if the standard of the fittings installed fails to meet that of the approved samples or if the fittings are found to be unsuitable for use in fresh water plumbing systems.

This acceptance is only applicable to the main body of the fittings, unless otherwise specified.

For the use of the fittings in any project, the General Acceptance Number of this letter must be quoted as a means of identification of acceptance of the fittings by this Authority.

Should you have any enquiries, please contact our Engineer Mr. Terry KUNG at tel. no. 3583 4086.

Yours faithfully,

(CHAN Chung-kun)

for Director of Water Supplies

Encl.

c.c. WSD 3321/1/82] - without catalogue ME/MC] - with soft copy only



Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk



INSTALLATION

STEP 1 - PREPARATION FOR MOUNTING THE FAUCET Shut off the water supply. 2 INLETS VERSION O-RING Remove the hexagonal nut, the disk and the gasket. Do not remove the GASKET O-ring from the base of the faucet. DISC STEP 2 - INSTALLING THE FAUCET Place the faucet with O-ring into the hole in deck or lavatory. Make sure the O-ring is located between the deck or lavatory and the bottom of the O-RING faucet. O-RING O-RING Slide the gasket, disk and hexagonal **↑** GASKET GASKET nut over the flexible hose and secure the faucet into place. ↑ DISC DISC 1 NUT NUT

Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012 E-mail: acme@acmesanitary.com.hk Website: www. acmesanitaryware.com.hk



INSTALLATION

STEP 3 - CONNECTING THE WATER SUPPLY

(1)

Connect the red flexible pipe to the hot water supply and the blue flexible pipe to the cold water supply.



MAKE SURE THAT THE FILTERS ARE INSTALLED BETWEEN THE FLEXIBLE PIPE AND THE SHUT OFF VALVE/ANGLE VALVE (NOT SUPPLIED).



Turn on the central water supply and the shut-off valves (angle valves).
Check for leaks.



STEP 4 - CONNECTING THE POWER SOURCE

BATTERY VERSION

Install the batteries in the battery box and attach the box to the wall underneath the sink.

The cable connection must point down. (You can use an optional extension cable in order to assemble the battery box up to 3 meters away from the sink.)



TRANSFORMER VERSION

Plug the transformer into the electricity socket and connect the connectors.



Acme Sanitary Ware Co Ltd



Acme Building, 22-28 Nanking Street, Kowloon, Hong Kong Tel: 2388 7171 Fax: 2710 8012
E-mail: acme@acmesanitary.com.hk
Website: www. acmesanitaryware.com.hk



TROUBLESHOOTING

PROBLEM INDICATOR		CAUSE	SOLUTION	
No water coming out of the faucet:	1. Sensor flashes continuously when user's hands are within the sensor's range.	Low battery.	Replace battery	
	2. LED in the sensor does not flash once when user's hands are within the sensor's range. 3. LED in the sensor flashes once when user's hands are within the sensor's range.	1. Range is too short.	Increase the range	
		2. Range is too long.	Decrease the range	
		3. Battery is completely used up	The battery must be replaced.	
		4. Unit is in "Security Mode"*		
		5. Sensor is picking up reflections from the washbasin or another object.	Eliminate cause of reflection.	
		1. Connectors between the electronic unit and solenoid are disconnected. 2. The water supply pressure is higher than 8 bar.	Connect the electronic unit connectors to the solenoid. Solenoid is located inside the body. Reduce the supply water pressure.	
		3. The water supply pressure is under 8 bars and yet the pressure in the faucet's body is higher. This situation could be caused by a sudden increase in the water supply pressure that the back check prevents from dropping, even after water supply pressure drops under 8 bars.	Shut off water supply and unscrew one of the flexible pipes in order to reduce the pressure that blocks the product.	
Water flow from spout does not stop:	1. Sensor flashes once when user's hands are within the sensor's range.	Debris or scale in solenoid	Clean or replace the solenoid.	
	2. LED in the sensor does not flash once when user's hands are within the sensor's range.	Sensor is dirty or covered.** Sensor is picking up reflections from the washbasin or another object.	Clean or eliminate case of interference. Decrease the range or eliminat cause of reflection.	
Water flow diminished		Filter or aerator is clogged or the solenoid is dirty.	Remove, clean, re-install	

^{* &}quot;Security Mode": If the sensor is covered for more than 90 sec. the faucet will automatically shut off water flow. In order to return to normal operation, remove any blockage.

^{**} In this case, the water flow will stop anyway after 90 seconds because of the security time.